

# Frequently Asked Questions

## Installation and Startup



### Which version of Microsoft ActiveSync should I install?

See *VIASAT GPS Systems – Settings and Communication*

### Can I install an EZTag CE license on more than one computer?

No. As stated in the *EZTag CE* end-user license agreement, the license activates a single machine for a single user.

### Does a version of EZTag CE running on Windows computers exist?

Yes. *EZTag CE for Windows* and *EZTag CE Viewer for Windows* run under the *Microsoft Windows* operating systems.

*EZTag CE for Windows* is licensed and requires a hardware security key to unlock all advanced features such as GPS data collection.

*EZTag CE Viewer for Windows* does not require a hardware key but provides access only to the following basic features:

- Mapping System Editor
- Dictionary Editor
- EZTag CE License Wizard
- Feature Conversion Wizard
- Capability to view field data.

### Which mobile platforms are supported by EZTag CE?

- Notebook or Tablet PC computers running Microsoft Windows 98 or higher or Microsoft Windows for Tablet PC;
- DAP Technologies handheld computers (CE5240(X), CE5320(X), CE3240) including Viasat 5000X and 3000X GPS Systems;
- Windows Mobile devices based on Intel ARM or compatible CPU (Pocket PC devices running Pocket PC OS 2002 or higher (**Note 1**)).

For the list of certified devices, refer to the *EZTag CE Release Notes* document.

**Note 1: Recommended device based on an Intel ARM compatible 400 MHz or higher processor with at least 64 MB of RAM.**

### Which operating systems are supported by EZTag CE?

- Microsoft Windows 98 or higher;
- Windows CE 3.00 or higher;
- Pocket PC OS 2002 or higher;
- Windows Mobile (.NET 4.20 or 5.0).

### What is the minimal configuration required to run EZTag CE?

Refer to the *EZTag CE Installation Guide* document for details.